



Warrior Products, Inc.  
16850 SW Upper Boones Ferry Rd  
Ste. A  
Durham, OR 97224  
Phone (888) 220-6861  
Fax (503) 692-0364  
[sales@warriorproducts.com](mailto:sales@warriorproducts.com)

---

## **TOW BAR**

### **INSTALLATION INSTRUCTIONS**

### **WAR 860**

**Depending on your application, either Bumper Attachment Bracket WAR861 or Tow Bar Shackles WAR159 or WAR162 are needed for installation.**

NOTE: Please read all instructions before starting installation of the TOW BAR.

Your Tow Bar should be installed by a professional installer or fabricator experienced at installing tow bars, and at wiring in lights on the tow vehicle. Points that need close attention:

1. Tow Bar should be as close to parallel with the ground as possible. You may need to alter the hitch on the tow vehicle to accomplish this. Drop hitches are available from Warrior Products in 2" increments.
2. Your coupler is designed to accept a 2" (two inch) ball only.
3. Bolt all attachments to the towed vehicle, welding is not recommended.
4. Fabricate a structure on the towed vehicle so that the Tow Bar is pulling on the frame only. If the Tow Bar is attached to a bumper, fabricate a support to the frame. (Similar to winch attachment)
5. Attach Tow Bar to the bumper attachment brackets or special tow bar shackles. Center the coupler on the tow bar side arms so they are on a centerline with your hitch. Tighten the two \_" bolts to 75 ft lbs. and the two 3/8" bolts to 45 ft lbs.
6. Install four safety chains (not provided). Two are attached between the coupler and the tow vehicle, and two between the support arms and the frame of the towed vehicle.

**You're done! Be sure to re-check all bolts often, even during trips.**

If you need further assistance installing your product, please contact us by email at [techsupport@warriorproducts.com](mailto:techsupport@warriorproducts.com) or call us at (888) 220-6861.

**THANK YOU FOR PURCHASING WARRIOR PRODUCTS**