



Protecting Your Adventure Lifestyle

Warrior Products, Inc.
16850 SW Upper Boones Ferry Rd
Ste. A
Durham, OR 97224
Phone (888) 220-6861
Fax (503) 692-0364
sales@warriorproducts.com

BACK PLATES

DIAMOND PLATE / STEEL

All “BACK PLATES” are designed to be placed over the existing metal surface under the tailgate area.

- 1) Be sure that the surface is flat before installing your Back Plate. A little body work may be needed. Be sure any bare metal surfaces are painted.
- 2) Lift the Back Plate up to the area under the tailgate and use it to determine where you want to place your mounting holes. Mark the mounting locations with a felt pen or other marker and remove for ease of drilling. If you are covering rust or damaged areas, try not to locate any mounting holes in these areas.
- 3) If using the “pop” rivets provided to attach your Back Plate, you will need to secure a drill, a 3/16” drill bit, and a “pop” rivet tool. Drill your mounting holes using the 3/16” drill bit.
- 4) Place your drilled Back Plate in location and mark through the holes onto the body. Drill mounting holes where indicated using your 3/16” bit. Be careful not to drill through anything that may be behind the body metal.
- 5) Install the Back Plate using the “pop” rivets supplied. If you prefer you can use self tapping bolts to install the plate.

CONGRATULATIONS! You have finished your installation. Enjoy your new Warrior Products Back Plate and be sure to look for other quality Warrior Products for your vehicle.