



# **JK**

## **ROCK SLIDERS**

1. POSITION THE SLIDER ON THE JEEP
2. LOCATE MOUNTING HOLE LOCATIONS WITH A MARKER
3. DRILL MOUNTING HOLES WITH A 1/4" BIT AND THEN FOLLOW THAT WITH DRILLING THE SAME HOLES WITH A 5/8" BIT. THIS WILL KEEP THE HOLES IN THE CORRECT LOCATION.
4. INSERT THE ENCLOSED WELL NUTS INTO THE MOUNTING HOLES.
5. WE RECOMMEND USING BLACK 100% SILICONE WHEN ATTACHING THE ROCK SLIDERS TO THE BODY OF THE VEHICLE. THIS WILL PROVIDE A STRONG CLEAN SEALED INSTALLATION.
6. APPLY THE SILICONE DIRECTLY TO THE BODY OF THE JEEP. APPLY A HEALTHY BEAD 1/2" FROM THE TOP EDGE OF THE SLIDER ENCIRCLING THE WELL NUTS. ALSO APPLY A HEALTHY BEAD ALONG THE LOWER EDGE OF THE VERTICAL BODY FACE. (AVOID APPLYING SILICONE IN THE AREA OF THE RIVER RAIDER LOGO IF YOU WANT THE BODY COLOR TO SHOW THROUGH)
7. USING THE SUPPLIED STAINLESS HARDWARE ATTACH THE SLIDER TO THE JEEP BODY
8. BE SURE TO USE A WET SPONGE WHEN SHAPING THE SILICONE TO A NICE FINISHED EDGE ALONG THE TOP EDGE OF THE SLIDERS
9. REPEAT STEPS ON THE OTHER SIDE.