



Protecting Your Adventure Lifestyle

Warrior Products, Inc.
16850 SW Upper Boones Ferry Rd
Ste. A
Durham, OR 97224
Phone (888) 220-6861
Fax (503) 692-0364
sales@warriorproducts.com

TUBE DOOR MIRROR BRACKET INSTALLATION INSTRUCTIONS WAR 1419

NOTE: These mirror brackets will fit any tube door with a 1 1/2" outer tubing diameter.

Installation:

1. Locate a spot on your tube door where you would like to mount your mirror brackets
2. Use the 6mm bolts and nuts to clamp the bracket to the tube door.
3. The included mirrors may have a 3-hole patterned bracket on the bottom. If they do, remove that bracket by removing the two nuts holding it on in the bottom of the mirror arm. Retain the two nuts and flat washer.
4. Install the mirrors onto the brackets by sliding the bottom of the mirror arm over the tube on the bracket. The threaded portion of the bottom stud will slide thru the hole and be accessible from the bottom of the brackets. Use the flat washer and nut you removed earlier to attach the mirror to the bracket. Tighten to a snug fit.
5. Sitting in your driver seat with the tube door closed; set the mirrors angle to the desired position and lock it into place by tightening the mirror to the bracket securely. Do not over tighten as you may damage your mirrors.
6. Finish the installation by hand adjusting the mirror lens to your preferred position.

Warrior also carries a full line of mesh covers, padding kits, and door limiting straps for your Tube Doors. Go to www.warriorproducts.com to view additional accessories available for your tube doors.

If you need further assistance installing your product, please contact us by email at techsupport@warriorproducts.com or call us at (888) 220-6861.

THANK YOU FOR PURCHASING WARRIOR PRODUCTS