

Warrior, Inc. 11100 SW Industrial Way Tualatin, Oregon 97062 (503) 691-8915 Main (503) 692-0364 Fax (888) 220-6861 Toll Free techsupport@warriorproducts.com

SUBJECT: Part #3841 FJ Cruiser Shovel & Axe Mount Install Instructions

NOTE: Please read all instructions before starting installation.

- 1. Begin by unpacking your kit. Be sure that you have two main plates with a stud attached, two outer plates which will be very similar to your main plate only without a stud, and two smaller inner plates.
- 2. Begin by deciding how far apart you want your mounts to be considering the handle length on your axe and shovel, and pick your locations for the main plates.
- 3. Sandwich your outer and inner plates around the tubes of the FJ rack with the stud in the middle of them. Clamp into place with supplied washer and nut.
- 4. Be sure you have both sets of plates where you want them to be located and tighten the nuts to secure them into place permanently.
- 5. Use the top and bottom indents on the bracket to line up the axe and shovel.
- 6. Use the outer plate and supplied wing nuts to clamp the shovel and axe into place.

