

OPEN FIRST!!

ENERGY SUSPENSION®

1131 VIA CALLEJON, SAN CLEMENTE, CA 92673

Parts list for Master set # 2-18102

© 2003 Energy Suspension. All rights reserved.
May not be reproduced, in any form, or by any means,
without the written consent of Energy Suspension.

Parts list:

Energy Suspension recommends that you read over all the installation instructions and parts list before you start.

Jeep tranny torque arm grommet set:

- 2 - 4403 bushings

Transmission mount: replaces factory part # 1370910

- 1 - 1036 mount
- 1 - 15.810 backing plate
- 2 - 15.348 (7/16" lockwasher)
- 4 - 15.342 (7/16" flat washer)
- 2 - 15.530 (7/16"-14 x 1" bolt)
- 1 - 17112 installation instructions

Front leaf spring and shackle bushing set:

- 4 - 2002 main eye bushings
- 2 - 15.007 (3/4" O.D. x 9/16" I.D. x 2.900" sleeve)
- 8 - 2003 rear spring eye and frame shackle bushings
- 1 - 17040 installation instructions

Rear leaf spring and shackle bushing set:

- 4 - 2223 main eye bushings
- 2 - 15.007 (3/4" O.D. x 9/16" I.D. x 2.900" sleeve)
- 8 - 2005 rear spring eye and frame shackle bushings
- use 17040 installation instructions

Body mount set:

- 10 - 4016 bushings, molded in sleeve (# molded on part)
- 8 - 4020 bushings (.450" hgt. x 1-1/4" I.D.)
- 2 - 4018 bushings (.950" hgt. x 1-1/4" I.D.)
- 1 - 4019 bushing (.400" hgt. x .675" I.D.)
- 1 - 4017 bushing, molded in nipple (# molded on part)
- 1 - 17032 installation instructions

Parts list continued:

Complete greaseable front swaybar bushing and endlink grommet set (15/16" diameter bar)

- 2 - 5339 (15/16" greaseable bushing)
- 2 - 15.815 greaseable bushing bracket
- 4 - 15.323 (.702" O.D. x .402" I.D. washer)
- 4 - 2201 upper and lower endlink grommets
- 1 - 17145 installation instructions

Tie-rod boot sets:

- 4 - 13001 tie-rod boots

Grease:

- 2 - 9.11101 grease tubs

Additional parts available

Front or rear bump stops

1976-79 all replaces O.E. part # J5355483
(2 per set) set # 9-9137

Shock boots

fits most aftermarket shocks (2 per set)
set # 9-

CJ 8 body mounts 1981-86 CJ8

set # 2-

Please refer to our newest catalog for more information on custom applications including bump stops, shock bushings, universal mounts, tie rod boots, ball joint boots, transmission mounts, etc. please ask to see catalog at your place of purchase.

17189

Updated 04/21/03 APF
Revised 3-12-2004 AN