

Jeep JK 4 Door Installation Instructions

PLEASE READ CAREFULLY BEFORE STARTING INSTALLATION

To safely lift and install this hardtop, you will need the assistance of at least one other person.

Follow the instructions and perform the steps in the sequence given. Short cuts to the directions may result in an unsatisfactory installation.

WARNING!

The top on this vehicle is designed only for additional protection against the elements.

Do not rely on the top to contain occupants within the vehicle or to protect against intrusion of foreign objects, nor injury during an accident.

Make sure all brackets and screws are tight. Periodically check for tightness and retighten when necessary.

WEAR SEAT BELTS AT ALL TIMES

Parts included in the installation kit.

6 each	Bolt 5/16 x 18 x 1 1/4
6 each	Nut 5/16 x 18
6 each	Washer 5/16
2 each	Front Windshield Clips
2 each	Mid Body Bolts 8mm x 1.25
2 each	Black Washers



1. Remove side windows. (Left & right)



2. Disengage front clips and remove 2 screws holding the retainer loop. Remove loop. Both sides.



3. Disengage soft top in rear corner. (Left & right)



4. Disengage soft top rear bar from retainers. (Left & right)



5. Remove retainers. (Left & right)



6. Disengage soft top from the top rail retainers. (Left & right)



7. Unscrew the 3 attach knobs along each side. (Left & right)



8. Remove soft top rail. (Left & right)



9. Disengage soft top mechanism



10. Disengage soft top mechanism at diagonal roll bar mount and remove mount. Remove soft top from vehicle.



11. Do Not Remove Front End Seals.



12. Do Not Remove Rear End Seals.



13. Using 4 people, place hardtop on the Jeep.



14. Install the side rail bolts using the supplied washers and nuts. Do not tighten.



15. Install a bolt on each side mid body.



16. Remove the factory hold downs. Left and right. Not the center.



- 16A. Install new hold down.

17. Tighten the rail bolts down and engage the front clips. Tighten the mid body bolts. Make sure the doors open and close freely. It may be necessary to adjust the top forwards or backwards.

Made with PRIDE in the USA.
ENJOY.