



Installation Instructions
for
Mirror Relocation Brackets for
1987-1995 Jeep® YJ Wrangler

Thank you for purchasing your new Skid Row Offroad Mirror Relocation Brackets. They are designed for your convenience both on and off the trail.

Your package should come complete with the following parts:

LEFT

- (1) Left Side Mirror Relocation Bracket
- (2) 5/16" Stainless Steel Flat Washers
- 2) 5/16-18 x .75" Button Head Cap Screws

RIGHT

- (1) Right Side Mirror Relocation Bracket
- (2) 5/16" Stainless Steel Flat Washers
- (2) 5/16-18 x .75" Button Head Cap Screws



If only one side was ordered, then only the parts for that side are included.

Step 1: Remove the original Torx head bolts from the sides of the upper part of the windshield hinge.

Step 2: Place one of the stainless steel 5/16" flat washers on each of the 5/16-18 Stainless Button Head Cap Screws and bolt the mirror bracket to the hinge as shown.

Step 3: Disassemble the mirror from the original mirror mounting bracket saving the nut and "cup" washer to be re-used. The parts will look like the picture below. The "cup" washer can be replaced with a standard flat washer if necessary.



Step 4: Remove the original mirror mounting bracket from the door.

Step 5: Mount the mirror into the new mirror relocation bracket using the flat washer and nut. Position the mirror and tighten the nut.



We hope you enjoy your new Skid Row Offroad mirror relocation brackets!

Sincerely,

The Staff at SFK Manufacturing, LLC

SFK Manufacturing, LLC
PO Box 306, Shermans Dale, PA 17090
Phone 717-701-8315
Fax 717-701-8316

www.SkidRowOffroad.com