



Warrior, Inc.
16850 SW Upper Boones Ferry Rd. Suite A
Durham, OR 97224
Phone: (888) 220-6861
Fax: (503) 692-0364
customerservice@warriorproducts.com
www.warriorproducts.com

2005 – 2015 Toyota Tacoma Entry Guards – Double Cab

P/N 4920 / 4920PC / S4920

Kit Contents:

<u>Item</u>	<u>Qty</u>	<u>Item</u>	<u>Qty</u>
Rivets	16	Entry Guards – FRONT	2
Entry Guards – REAR	2		

Installation Instructions:

NOTE: 3M Tape may be used to install entry guards if you do not wish to drill and install using rivets.

1. Locate and separate the front and rear pairs of entry guards. The front pair will be the longest.
2. Separate each set into driver side and passenger side entry guards. When looking into the vehicle, the stamped “WP” will be on the rear-most side of the entry guard.
3. Begin with the front driver’s side entry guard and center the entry guard visually in the entry way.
4. Push the entry guard firmly against the door jam and mark 4 holes with a sharpie. One in each corner.
5. Remove plate and drill holes with 3/16th drill bit.
6. Replace plate, pressing the plate firmly against the door jam.
7. Insert a rivet loosely into each of the four holes.
8. After all four rivets are located in each of the four corners, use a rivet gun to clench all four rivets into place.
9. Repeat steps 4 – 8 for each remaining entry guard.
10. Installation Complete.

If you need further assistance installing your product, please contact us by email at customerservice@warriorproducts.com or call us at (888) 220-6861.