


Renegade Budget Boost Instructions

www.teraflex.com

#1351200




Important Notes:

Prior to beginning this or any installation read these instructions to familiarize yourself with the required steps and evaluate if you are experienced and capable to personally perform these modifications. A factory service manual should be used in conjunction with these installation instructions.


Refer to the parts list to ensure that all necessary components and hardware has been included. If any parts are missing please contact your local TeraFlex dealer for assistance.

Tools needed:

- Tools needed:**
- Basic mechanics tool set
 - E-12 Reverse Torx Socket
 - E-14 Reverse Torx Socket
 - E-16 Reverse Torx Socket
 - E-20 Reverse Torx Socket
 - T-40 Torx
 - Blue Thread Locker
 - Drill and 17/32 " Drill Bit



ITEM #	PART #	DESCRIPTION	QTY.
1	351210	Jeep Renegade Budget Boost Rear Aluminum Strut Spacer	2
2	351220	Jeep Renegade Budget Boost Front Aluminum Strut Spacer / Driver	1
3	351225	Jeep Renegade Budget Boost Front Aluminum Strut Spacer / Passenger	1
4	351231	Upper Charcoal Canister Relocation Bracket For Renegade, Aluminum	1
5	351241	Lower Charcoal Canister Relocation Bracket For Renegade Aluminum	1
6	351270	Control Arm Spacer for Renegade Budget Boost	2
7	753005	JK 3"-4" Front Quick Disconnect Swaybar Link w/ Upper Swivel Stud	2



ITEM #	PART #	1753100 RENEGADE HARDWARE & SPACER KIT	QTY.
1	308	Grease Zerk 1/4"-28 UNF Straight	2
2	11396	Bolt, M10-1.25 X 45mm, EcoGuard, Hex Cap Screw	2
3	38621	Bolt, M8-1.25 X 50mm, EcoGuard, Hex Cap Screw	4
4	39623	Bolt, M10-1.5 X 50mm, EcoGuard, Socket Cap Screw	12
5	40357	Washer, M8 X 16mm OD, EcoGuard, Flat Washer	4
6	40358	Washer, M10 X 20mm OD, EcoGuard, Flat Washer	10
7	40359	Washer, 7/16" x 1.250" OD, Ecoguard, Flat Washer	8
8	40360	Washer, M14 X 28mm OD, EcoGuard, Flat Washer	4
9	43745	Bolt, M14-2.0 X 150mm, EcoGuard, Hex Cap Screw	4
10	53991	Bolt, M10-1.5 X 55mm, EcoGuard, Hex Cap Screw	8
11	90700	Nut, M6-1.0, EcoGuard, Flange Nut	3
12	37	Washer 1/2" Flat Zinc Plated	2
13	3801	Washer 3/4" x .124" Thick Flat Zinc Plated for QD Link Pin	2
14	477	Washer 7/16" Flat Stainless Steel	2
15	488	Nut 1/2"-20 UNF Stainless Nylock for QD4 SS	2
16	56-13-08-438-2-1	Spacer, 1.25" OD, 0.75" Length, .438" ID, Aluminum 6061-T6, No Finish	2
17	56-13-10-375-2-1	Spacer, 1.25" OD, 1.00" Length, .375" ID, Aluminum 6061-T6, No Finish	4
18	56-20-15-063-2-1	Spacer, 2.00" OD, 1.50" Length, .625" ID, Aluminum 6061-T6, No Finish	4
19	600499	Universal 3/4" Diameter Axle Side Quick Disconnect Stud	2
20	600503	5/8" Diameter Upper Quick Disconnect Parking Stud	2
21	600504	Quick Disconnect Bow Tie Pin	2
22	616	Nutsert 3/8"-16, .150-.312" Grip Length, Carbon Steel, Zinc Yellow Plus Lubricant	2
23	746	Nutsert Installation Tool for 3/8" Nutsert, Jeep Renegade	1

Refer to the factory service manual for lift locations. Raise and support the vehicle with jack stands. Note, jack stands must not be under suspension components.

Remove the tires and wheels.

1

Raise the hood. Mark the orientation and side (LH and RH) of the windshield wipers, then remove using a 17mm.



2

Remove the 7 plastic clips that attach the cowl. Then remove it to gain access to the strut mounts.




3

After cowl and wipers are removed the wiper arm assembly will need to be cycled partially to gain access to one of the strut bolts being blocked by it. To do this, turn the ignition to the on position and turn on the wind shield wipers. Before the motor can cycle back to its resting position turn the ignition off. This will leave the arm assembly out of the way.



4

Starting with the right side, remove the brake line and the ABS wiring from the front strut.




5

Using a T-40 torx and an 18mm box end wrench, remove the front sway bar link.




6

With a punch and hammer, bend the keyway nut tabs out of the axle keyway. Then remove nut and press shaft only enough to free it of the hub assembly.




7

With an E-16 Reverse Torx and a 16mm, remove the 2 bolts that attach the steering knuckle to the strut and separate.



8

Remove the 3 upper strut bolts with an E-14 Reverse Torx and remove the strut.




9

Place the front right spacer (spacer with the R) on top of the strut. Apply blue loctite to and install three 10M X 50mm Allen Bolts into strut through recessed holes. With a 8mm Allen **torque bolts to 70 ft-lbs.**




10

Re-install the strut using the factory bolts in the bolt holes of the spacer. The letter R will go toward the front of the Jeep. Do not apply loctite to these bolts. **Torque to 50 ft-lbs.**



11


Reconnect the knuckle to the strut and axle shaft using the original hardware. **Torque knuckle to strut bolts to 90 ft-lbs. Torque axle nut to 148 ft-lbs.** Bend keyway tabs into keyway. Repeat steps 5-12 for the driver side.



12


Insert the lower stud of the quick disconnect sway bar linkage into the factory sway bar. Place 7/16" washer and M12 nylock nut onto the stud. Use a 6mm allen to hold the stud, tighten down the nut with a 18mm wrench.

Torque to 75 ft-lbs.



13


Insert 3/4" upper stud onto strut bracket as shown. Place 1/2" washer and nylock nut onto the upper stud.
Note: The stud is stainless steel and the threads are soft. Take care to not over tighten the nut.



14

Slide the upper end of sway bar link onto the stud installed into strut. Place 3/4" washer on stud and insert Bow Tie Pin.

Note: This should be a tight fit for better sway bar function. Applying a bit of grease to the stud and bushing will help with install.




15

Trim fender liner as shown.




16

Use template cut out on second to last page of instructions to mark location for nutsert.
Use a center punch to help center the drill bit when drilling. Drill a pilot hole in marked location.
Drill hole out to 25/64".




17

Paint the drilled hole to help prevent rust from forming. Use supplied nutsert tool to install nutsert.
Install upper 5/8" park stud into nutsert as shown.
Note: The stud is stainless steel and the threads are soft. Take care to not over tighten the park stud.
Repeat steps for other side.



18

Reattach brake and ABS lines to strut.



19

Before installing the wipers turn the key on with wiper switch in the off position. This will allow wiper motor to cycle back to it's off and down position. Other wise **damage may occur**. Reinstall cowl and windshield wipers.



20

Starting with the right rear side, remove the plastic inner fender. There are five Philips screws, one plastic nut and four 10mm nuts.



21

Disconnect the charcoal canister lines and remove the canister with a 10mm.



22

Disconnect the sway bar link from the strut with a T-40 Torx bit and an 18mm.




23

Loosen the unibody side lower control arm bolt with an E-20 Reverse Torx and a 17mm. Do not remove.




24

With an E-14 Reverse Torx, unbolt the lower control arm bracket from the frame.




25

Install the spacers and four M10 x 55mm bolts (with loctite), M10 washers and 7/16" x 1.25" OD washers. Larger washer goes up against control arm bracket.




26

While tightening M10 bolts press the control arm bracket to the rear of the Jeep. *See illustration below*
With a 19mm torque bolts 75 ft-lbs.



27

Remove the bolt supporting the exhaust bracket. Insert provided 1.00" spacers and install M8 X 50mm bolt with washer. Apply blue loctite and use a 13mm to tighten.



28

Remove the bolt supporting the brake/abs lines bracket. Insert provided 1.00" spacers and install M8 X 50mm bolt with washer. Apply blue loctite and use a 13mm to tighten.

Repeat steps 16-22 for the left side.




29

Support the lower sub-frame on a jack. Remove the 4 bolts with an E-20 Reverse Torx.



30

Lower the sub-frame enough to install 1.50" spacers. Install the supplied M14 x 150mm and **torque to 120 ft-lbs** with a 22mm.



31

Loosen the 2 bolts supporting the driveline carrier bearing with a E-12 Reverse Torx. Apply blue loctite to two M10 X 45mm bolts. Remove one bolt, insert 0.75" spacers above support and install a M10 bolt with a washer. Repeat for other bolt and tighten new bolts with a 17mm.



32

Remove ABS line, e-brake cable and hydraulic brake line from passenger side knuckle.



33

With an E-16 Reverse Torx and a 16mm, remove the 2 bolts that attach the knuckle to the strut.




34


Remove the 3 upper bolts with an E-16 Reverse Torx and remove strut. Install spacer using 10M x 50mm Allen Bolts, **with blue loctite**, into recessed holes (no washers). With an 8mm allen **torque bolts to 70 ft-lbs**.



35




Re-install strut with factory hardware. ***No Loctite*** While tightening upper bolts press top of strut toward the center of the Jeep. This will help with alignment. **Torque upper strut bolts to 50 ft-lbs. Torque knuckle bolts to 90 ft-lbs.** Repeat steps 33-36 for the left side.




36

Install the upper charcoal canister bracket using the supplied M6 nut, oriented as shown, and tighten nut



37

Install the lower charcoal canister bracket using the supplied M6 nut, oriented as shown, and tighten nuts.



38

Mount the charcoal canister to the new brackets using factory hardware and tighten the nuts. Re-attach the lines.



39

Re-connect the sway bar links. **Torque to 59 ft-lbs.**



40

Reinstall the inner fenders.




41

Install the tires and torque lug bolts.
Lower Jeep to the ground.

Steel Wheels	63 ft-lbs	86 N-m
Aluminum Wheels	89 ft-lbs	120 N-m

42

With Jeep on the ground torque lower control arm bolts to 110 ft-lbs.



Check to make sure all bolts and nuts are torqued according to specification.

Jeep is safe to drive but **to avoid excessive tire wear an alignment is necessary** and needs to be done as soon as possible.

Note: Re-torque all components after 100 miles and inspect every 3000 miles after that.

CUT OUT TEMPLATE




REST TEMPLATE ON
EDGE OF BRACKET



CENTER THIS HOLE ON
FENDER LINER STUD

DRILL HOLE HERE



PRODUCT INFORMATION

MAINTENANCE INFORMATION:

It is the buyer's responsibility to have all suspension, drivetrain, steering, and other components checked for proper tightness and torque after the first 100 miles and every 3000 miles after that.

NOTICE TO INSTALLER:

The enclosed "Warning to Driver" sticker must be installed in the vehicle in driver's view. This sticker is to act as a constant safety reminder when operating the vehicle. It is your responsibility as the equipment installer to install the provided sticker and to forward the product instructions to the vehicle's owner for review. If a "Warning to Driver" sticker or product installation guide were not included in the kit, FREE replacement stickers and instructions are available by request. It is the installer's duty to ensure a safe and controllable vehicle after the modifications have been performed.

WARNING:

Neither the seller nor the manufacturer will be liable for any loss, damage, or injury directly or indirectly arising from the use of or inability to determine the use of these products. Before using, the user shall determine the suitability of the products for its intended use, and the user shall assume all responsibility and risk in connection therewith.

WARNING TO DRIVER:

This vehicle has been modified to enhance off road performance and has unique handling characteristics. Use in harsh environments can cause extreme stress on the components. Vehicle should be inspected after being off road to make sure that all the components are in working order and safe to travel on the highway. All fasteners should be checked so that they are at the correct torque specifications as the vibration and stresses from off roading may cause critical fasteners to work loose. Extra care should be taken to inspect the critical components, steering, and brake systems. During each oil change components such as arms, tie rod ends, etc should be greased and checked for excessive wear. Any worn components should be replaced. When returning to the pavement always set or restore tire air pressure to the factory recommendation and connect or engage any disabled sway bar mechanisms. Because of the higher center of gravity and larger tires, this vehicle handles and reacts differently than many passenger cars, both on and off road. You must drive it safely! Extreme care should be taken to prevent vehicle rollover or loss of control, which can result in serious injury or death. Avoid sudden sharp turns or abrupt maneuvers. Generally, braking performance and capabilities are decreased when significantly larger/heavier tires are used, especially when used in combination with transfer case low-range blueuction kits. Take this into consideration while driving. Do not add, alter or fabricate any factory or aftermarket parts to increase vehicle height over the intended height of the TeraFlex product purchased. Mixing component brand is not recommended. TeraFlex Inc. will not be responsible for any alteblue product or any improper installation or use of our products. We will be happy to answer any questions concerning the design, function, and correct use of our products. It is ultimately the buyer's responsibility to have all bolts/nuts checked for tightness after the first 100 miles and then every 3000 miles. Wheel alignment, steering system, suspension and drive line systems must be inspected by a qualified professional mechanic at least every 3000 miles.

TERAFLEX PRODUCT WARRANTY:

TeraFlex Inc. warrants TeraFlex Suspension products to the original retail purchaser to be free of defects in material and workmanship for as long as the original purchaser owns the vehicle on which products were originally installed.

Failure to complete regular maintenance (grease every 3000 miles) on TeraFlex FlexArms will void this warranty. All other conditions of the standard TeraFlex product warranty apply.

All TeraLow products are coveblue by the TeraFlex two (2) year warranty to be free of defects in material and workmanship for two years from date purchased.

TeraFlex axles are coveblue by a 12-month warranty to be free of defects in materials and workmanship.

This warranty does not cover or include product finish, improperly installed or applied products, improperly maintained products, products or components used for racing or competition or damage due to abuse or neglect, products that fail due to the use of larger tire and wheel combinations.

All returns must be accompanied by an original invoice. It is the customer's responsibility to remove the product from the vehicle. Shipping charges are the responsibility of the customer. TeraFlex Inc. will pay the return freight if the product meets the terms of warranty.

This warranty is for the replacement or repair of defective TeraFlex products only and does not include freight charges, labor charges for removal of or installation of TeraFlex or related products or components, costs incurblue due to down time of the vehicle, or lost profits due to vehicle down time.

A returned goods authorization number (RGA#) must accompany any returned products. For more information please contact a TeraFlex customer service representative.

COPYRIGHT

©Copyright 2014. All rights reserved, TeraFlex Inc. Reproduction of this catalog and/or any of its contents without written permission is strictly prohibited.

TeraFlex® is a registebblue trademark of TeraFlex Inc. All trade names and logos including but not limited to TeraFlex, FlexArms, RockGuard, Monster, and LCG are protected by law and duplication of trade names and/or logos are strictly prohibited.

TeraFlex Inc. reserves the right to update, discontinue, blueesign, modify finish, part number or component build parts if deemed necessary without written notice.

TeraFlex Inc., and any associated dealers are not responsible for misprints or typographical errors that may have inadvertently been made within this instruction sheet.

Jeep® and the Jeep® grill are registebblue trademarks of Fiat Chrysler Automobiles N.V., and have no affiliation with TeraFlex Inc.

TERAFLEX, Inc.

5680 West Dannon Way
West Jordan, Utah 84081
Phone/801.713.3314
Fax/801.713.2313
www.teraflex.com